




©2017 WWW.SHANTY-2-CHIC.COM



DIY Fancy Full Bed

SUPPLY LIST

| Item | Quantity | Description |
|---------------------------|----------|--------------------------|
| 1x6x6 | 10 | Common Boards or Pine |
| 1x4x6 | 13 | Common Boards or Pine |
| 2x4x8 | 9 | Framing Lumber |
| 2x2x8 | 3 | Framing Lumber or Pine |
| 1x8x8 | 2 | Common Boards or Pine |
| 1x8x6 | 1 | Common Boards or Pine |
| 1/4"x48"x96 | 1 | Hardwood Plywood (Birch) |
| 1 1/4" Pocket Hole Screws | | |
| 2 1/2" Pocket Hole Screws | | |
| 2 1/2" Wood Screws | | |
| 1 1/4" Wood Screws | | |
| 5/8" Brad Nails | | |
| 1" Brad Nails | | |
| Wood Glue | | |

Remember!

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!

CUT LIST (page 1)

| | | | | | | |
|-------|---|---|---|---|---|---|
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1x6x6 | 0 | 0 | 0 | 0 | 0 | 0 |

60"


| | |
|-------|--|
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |
| 1x4x6 | |

55"

Remember!

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!

CUT LIST (page 2)




Remember!

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!

CUT LIST (page 3)


1/4"x48"x96"



Note: I ripped the round edges off of all the 2x4 boards to make them 3" wide. This is not a necessary step but if you choose to not rip your boards, modify the plans accordingly.




Cut the headboard planks to size and drill $\frac{3}{4}$ " pocket holes along the edges according to the picture below. Attach the planks together with $1 \frac{1}{4}$ " pocket hole screws.







Mark for the headboard design, trace a line with a pencil and use a jigsaw to cut the headboard design.






Trace the top of the headboard on the 1/4" plywood for the headboard trim and cut it using a jigsaw. Using a projector, trace the bottom design and cut it with a jigsaw. Attach the trim to the headboard with 5/8" brad nails and wood glue.




4

Cut the posts to size and attach them to the headboard with 1 1/4" pocket hole screws and wood glue.. The top of the posts should be flush with the ends of the headboard.




5

Cut the middle trim and bottom trim to size. Center the middle trim and place the bottom trim 4 3/4" from the bottom of the headboard. Use 5/8" brad nails and wood glue to attach the center trim and 1" brad nails and wood glue to attach the bottom trim.



6


Cut the side panel pieces to size and drill 1 1/2" pocket holes according to the plans. Attach the top and bottom runners to the big panel with 2 1/2" pocket hole screws and wood glue. Build two of these assemblies.



x2


7

Cut the cleats to size and drill 1 1/2" pocket holes at each end. Attach them to each side panel with 2 1/2" wood screws and wood glue.




8

Cut the footboard pieces to size and drill $\frac{3}{4}$ " and $1\frac{1}{2}$ " pocket holes according to the plans. Attach the top and bottom runners to the panel with $1\frac{1}{4}$ " and $2\frac{1}{2}$ " pocket hole screws and wood glue.




9

Cut the legs to size and attach them to the side of the footboard panel with $2\frac{1}{2}$ " pocket hole screws and wood glue.



10


Cut the footboard trim to size. Attach it to the top of the footboard with 1 1/4" pocket hole screws and wood glue.




11

Attach the side panels to the footboard with 2 1/2" pocket hole screws. The inside of the side runners should be flush with the inside of the legs.

Inside of legs




flush




12

Attach the side panels to the headboard with 2 1/2" pocket hole screws. The inside of the side runners should be flush with the inside of the legs.




flush




inside of legs

13

Center and attach the middle cleat to the headboard and footboard with 2 1/2" pocket hole screws and wood glue.




footboard




flush

headboard




14

Cut the slats to size and spread them out evenly over the cleats. Attach them to the bed with 1 1/4" wood screws.



Now just fill your screw holes, sand it down and give it a finish!

Make sure to share your builds with us on social media and use #shanty2chic so we can share them too!



Happy Building!