



©2017 WWW.SHANTY-2-CHIC.COM



# EASY BARN DOOR

## SUPPLY LIST


Item	Quantity	Description
1x6x8	1	Pine or Common Boards
1x4x8	1	Pine or Common Boards
1x2x8	4	
48"x96" Barn Wood MDF	1	Birch
Wood Glue		
Barn Door Hardware		

*Remember!*


Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!

## CUT LIST



1x6x8



1x2x8  
1x2x8




1x2x8  
1x2x8



4'x8' Barn Wood MDF

1

Cut the studs and top and bottom frame pieces to size. Drill  $\frac{3}{4}$ " pocket holes at the ends of each stud. Attach the stud pieces to the top and bottom frame pieces with  $1 \frac{1}{4}$ " pocket hole screws and wood glue.




2

Cut the barn wood MDF to size and attach it to the frame with  $\frac{3}{4}$ " staples and wood glue. If you don't have a stapler, you can use brad nails. *Note: this door is covering a closet so I did not put a sheet of MDF on the back. If your door will be seen on the back side, you can attach a sheet of MDF on the back, the same way.*



3

Measure and cut the top and bottom trim pieces to size. Attach them to the barn door frame with 1 1/4" brad nails and wood glue. The front of the trim pieces should be flush with the front of the barn wood.



4

Measure and cut the side trim pieces to size. Attach them to the side of the barn door frame with 1 1/4" brad nails and wood glue.



Add a finish to the trim and you are ready to attach your new barn door to the wall!  
You can find the barn door hardware that we used in the post on our site!

Make sure to share your builds with us on social media and use #shanty2chic so we can share them too!

Happy Building!

