



1

Cut the side pieces to size and drill 1 1/2" pocket holes in the two side boards. Attach the side pieces to the top pieces with 2 1/2" pocket hole screws and wood glue. Build two frames.





2

Cut the mesh to size and attach it to the back of the side assemblies with 3/4" staples.




3

Cut the front and back frame pieces to size and drill 1 1/2" pocket holes into the ends of the top and bottom apron pieces. Attach the apron pieces to the legs with 2 1/2" pocket holes and wood glue. Build two frames.



4


Cut the vertical dividers to size and drill 1 1/2" pocket holes in both ends. Attach them to the top and bottom apron pieces with 2 1/2" pocket hole screws and wood glue. Do this for both frames.



5


## \*FRONT FRAME ONLY

Cut the horizontal dividers to size and drill  $\frac{3}{4}$ " pocket holes into both ends. Attach them to the vertical dividers with  $1\frac{1}{4}$ " pocket hole screws and wood glue.




6

Cut the mesh to size and attach it to the back frame with  $\frac{3}{4}$ " staples.







Attach the side assemblies to the back frame with 2 1/2" pocket hole screws and wood glue.



flush




Attach the front frame to the side frames with 2 1/2" pocket hole screws and wood glue.






9

Cut the bottom supports to size and drill  $\frac{3}{4}$ " pocket holes into both ends. Attach them to the bottom front and back aprons with  $1\frac{1}{4}$ " pocket hole screws and wood glue.




10

Cut the bottom panel to size and drill  $\frac{3}{4}$ " pocket holes around all edges. Slide it on top of the bottom supports and attach it to the bottom and side aprons with  $1\frac{1}{4}$ " pocket hole screws and wood glue. The bottom panel should be flush with the top of the bottom aprons.




11

Cut the top support pieces to size and drill 1 1/2" pocket holes into both ends. Attach them to the top aprons with 2 1/2" pocket hole screws and wood glue.



12


Cut the center dividers to size and drill 3/4" pocket holes around all edges. Attach them to the vertical dividers with 2 1/2" pocket hole screws and wood glue.



# DOORS


13

Cut the door pieces to size and drill 1 1/2" pocket holes into the side boards. Attach them to the top and bottom pieces with 2 1/2" pocket hole screws and wood glue.




14

Cut the mesh to size and attach it to the back of the door frames with 3/4" staples.



17


Cut the top and middle drawer pieces to size and drill 3/4" pocket holes into the ends of the long pieces. Attach the long pieces to the short pieces with 1 1/4" pocket hole screws and wood glue. Build 2 drawers.



x2

18


Cut the drawer bottoms to size and attach them to the bottom of the drawer frame with 3/4" staples and wood glue.



x2


17

Cut the bowl drawer pieces to size. Drill 3/4" pocket holes into both ends of the long pieces and attach them to the short pieces with 1 1/4" pocket hole screws and wood glue.



18


Cut the top piece of the dog bowl to size and use a jigsaw to cut the circles for the bowls. Attach the top inside the frame and use 1 1/4" brad nails and wood glue to attach. The top should be flush with the top of the frame.






19

Install the drawers inside the cabinet with drawer slides. You can get more details on how we installed ours in the post on our site!




20

Cut the drawer face pieces to size and attach them to the front of the drawers with 1 1/4" wood screws, from the inside of the drawer and into the back of the drawer face.




21

Cut the top panel to size then, measure and cut the side trim pieces to size. Attach the side trim pieces with wood glue and 1" pin nails.



22

Measure and cut the front and back trim pieces to size. Attach them to the top panel with 1" pin nails and wood glue.



To attach the top, use 1 3/4" wood screws from the top supports and into the plywood top.

Now, just add a finish, hardware and dog bowls  
and you're done!

Make sure to share your builds with us on social  
media and use #shanty2chic so we can share  
them too!

Happy Building!

