


We ripped the round edges off of all of the 2x boards. This made the 2x6 boards 5" wide and the 2x4 boards 3" wide. This is not a necessary step but if you choose to not rip your boards be sure to adjust the plans accordingly.


1

The first step is to plank the table top. Cut the planks to size and drill 1 1/2" pocket holes down one edge of all but one of the boards and at the ends of each board. Attach them together with 2 1/2" pocket hole screws.




2

Measure and cut the breadboards to size. Attach them to the ends of the table top planks with 2 1/2" pocket hole screws.




3

Cut the base plywood to size and drill 3/4" pocket holes around the edges. Cut the base frame pieces to size and attach them to the plywood with 1 1/2" pocket hole screws and wood glue. The top of the plywood should be flush with the top of the frame pieces.




4

Cut the bottom support pieces to size and drill 1 1/2" pocket holes at the ends of each board. Attach them to the bottom of the bottom base with 2 1/2" pocket hole screws and wood glue.




5

Cut the casing to size and attach it to the base frame with 1 1/4" brad nails and wood glue.




6

Cut the second base plywood to size and drill 3/4" pocket holes along the edges. Cut the frame pieces to size, drill 3/4" pocket holes on the front edges and attach them to the plywood with 1 1/4" pocket hole screws and wood glue.






Center the second base on top of the first base and attach it to the plywood with 1 1/4" pocket hole screws and wood glue.




Cut the trim to size and attach it to the second base frame with 1 1/4" brad nails and wood glue.




9

Cut the third base plywood to size and drill $3/4$ " pocket holes around the edges. Cut the frame pieces to size, drill $3/4$ " pocket holes along one edge of each board and attach them to the plywood with $1\ 1/4$ " pocket hole screws and wood glue.




10

Center the third base on the pedestal and attach it to the second base plywood with $1\ 1/4$ " pocket hole screws and wood glue.




11

Cut the trim pieces to size and attach them to the third base frame with 1 1/4" brad nails and wood glue.




12

Cut the trunk pieces to size. Rip the edges at a 45° angle with a table saw or miter saw. Attach the pieces together with 1 1/4" brad nails and wood glue.



13

Center the trunk on the third base and attach it to the plywood with 1 1/4" pocket hole screws and wood glue.



14

Cut the first row of trim to size and attach it with 1 1/4" brad nails and wood glue.

