



©2017 WWW.SHANTY-2-CHIC.COM




# Barn Wood Console

## SUPPLY LIST

Item	Quantity	Description
1x2x6	1	Whitewood or Common Boards
1x2x8	2	Whitewood or Common Boards
1x3x8	1	Whitewood or Common Boards
1x4x8	1	Whitewood or Common Boards
1x6x6	4	Whitewood or Common Boards
2x4x8	4	Framing Lumber
3/4"x48"x96"	1	Hardwood Plywood (Birch)
1/4"x48"x48"	1	Hardwood Plywood (Birch)
1 1/4" Brad Nails		
3/4" Pin Nails		
1 1/4" Pocket Hole Screws		
2 1/2" Pocket Hole Screws		
Barn Wood Planks		Link in Post on our Site
Wood Glue		
3" Hinges	4	Link in Post on our Site
Pulls	2	Link in Post on our Site

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!



# CUT LIST PAGE 1



*Remember!*

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!



## CUT LIST PAGE 2



***Note: We ripped the round edges off of the 2x4 boards, to make them 3" wide. This is not a necessary step but if you choose not to rip your boards, make sure to adjust the measurements.***

**1**

**Cut the plywood and legs to create the side panels. Drill  $\frac{3}{4}$ " pocket holes into each side of the plywood. Attach a leg to each side with  $1\frac{1}{4}$ " pocket hole screws and wood glue. The top of the legs should be flush with the top of the plywood and there should be a  $\frac{3}{4}$ " gap on the front of the panels and a  $1\frac{1}{2}$ " gap on the back. Build two of these assemblies.**




**x2**






**Measure and cut the top and bottom, side panel trim to size. Flip the side panels right-side-up and attach the trim pieces to the front of the side panels with 1 1/4" brad nails and wood glue.**





**Cut the back aprons to size and drill 3/4" pocket holes into both ends. Attach them to the back legs with 1 1/4" pocket hole screws and wood glue, flush with the inside of the legs. The bottom apron should be 2" from the bottom of the legs and the top apron should be flush with the top of the legs.**




4

Cut the front aprons to size and drill 1 1/2" pocket holes into each end. Attach the aprons to the front legs with 2 1/2" pocket hole screws and wood glue. The top apron should be flush with the top of the legs and the bottom apron should be attached 2 1/2" from the bottom of the legs.




5

Cut the bottom support pieces to size and drill 1 1/2" pocket holes into the ends that will attach to the front apron. Drill 3/4" pocket holes on the other ends. Attach the supports with 1 1/4" and 2 1/2" pocket hole screws and wood glue.




Notice the outside support pieces have one 1 1/2" pocket hole drilled on the back.






**Cut the plywood for the bottom of the cabinet. Apply wood glue to the top of the bottom support pieces, lay the plywood on top of the supports and attach it to the supports with 1 1/4" brad nails.**




**Cut the back support piece to size and drill 3/4" pocket holes into both ends. Center it on the back aprons and attach it to the back aprons with 1 1/4" pocket hole screws and wood glue.**






**Cut the front divider to size and drill 3/4" pocket holes into each end. Center it on the front aprons and attach it to the front aprons with 1 1/4" pocket hole screws and wood glue. The back of the divider should be flush with the back of the aprons and set back 3/4" from the front.**




**BACK**



**FRONT**



**Cut the 1/4" plywood to size and attach it to the back of the cabinet with 3/4" staples and wood glue.**




**BACK**

# DOORS


10


Measure and cut the door planks to size and line them up side-by-side on a flat surface.




11

Cut the trim pieces to size and attach them to the front of the planks with 3/4" pin nails and wood glue.





**Cut the top planks to size and drill 3/4" pocket holes along one edge of three of the planks. Attach them together with 1 1/4" pocket hole screws.**



**Attach the planked top to the the cabinet with 1 1/4" brad nails and wood glue. Attach the doors with hinges and add a finish!**

**Make sure to share your builds with us on social media and use #shanty2chic so we can share them too!**

**Happy Building!**