




Barn Door Storage Hack

SUPPLY LIST


Item	Quantity	Description
1x4x8	1	Pine or Common Board
1x2x8	2	Pine or Common Board
1/2"x3/4"x48" trim	2	Pine or Common Board
1/2"x24"x48" Hardwood Plywood	1	Birch
3/4"x24"x48" Hardwood Plywood	1	Birch
1 1/4" Pocket Hole Screws		
5/8" Brad Nails		
1 1/4" Brad Nails		
Wood Glue		
Cubby Storage Cabinet	1	Link in Post on our Site
Barn Door Hardware	1	Link in Post on our Site

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!

CUT LIST




Cut the top panel board to size and attach it to the top of the cabinet with 1 1/4" brad nails and wood glue. There should be a 1/4" overhang on the sides and front of the panel and the panel should sit 1/4" from the back.






Cut the side trim pieces to size and attach them to the sides of the top panel with 1 1/4" brad nails and wood glue.






Cut the front and back trim pieces to size and attach them to the top panel with 1 1/4" brad nails and wood glue.






Cut the side trim pieces to size and attach them to the sides of the cabinet with 1 1/4" brad nails and wood glue.






Cut the front trim piece to size and attach it to the front of the cabinet with 1 1/4" brad nails and wood glue.




6

Cut the barn door frame pieces to size and drill 3/4" pocket holes in the middle boards and the side boards. Attach them together with 1 1/4" pocket hole screws and wood glue.





Cut the back panel for the barn door to size. Attach it to the back of the barn door frame with 5/8" brad nails and wood glue, through the back panel and into the frame.



Add a finish and attach the barn door to the cabinet with barn door hardware!

Make sure to share your builds with us on social media and use #shanty2chic so we can share them too!

Happy Building!