



©2017 WWW.SHANTY-2-CHIC.COM



DIY OUTDOOR SOFA


SUPPLY LIST

Item	Quantity	Description
2x6x8	8	Framing Lumber
2 1/2" Pocket Hole Screws		
2 1/2" Outdoor Wood Screws		
Wood Glue		


Remember!

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!

CUT LIST




Miter Detail:



Note: I ripped all of my boards to 4 1/2" wide. This is not a necessary step but if you choose not to rip your boards, make sure to adjust the plans accordingly.


1

Cut the legs and arms to size, drill 1 1/2" pocket holes at one end of each of the leg pieces and attach them to the arms with 2 1/2" pocket hole screws and wood glue. Build 2 arm assemblies.



2


Cut the side runner to size, drill 1 1/2" pocket holes at both ends and attach it between the legs with 2 1/2" pocket hole screws and wood glue.



3


Cut the bottom runners to size and drill 1 1/2" pocket holes at both ends.

Attach them at the bottom of each side with 2 1/2" pocket hole screws and wood glue.




4

Cut the cleats to size and attach them to the side, slat support with 2 1/2" wood screws and wood glue.




5

Cut the back runner to size and drill 1 1/2" pocket holes at both ends. Attach it to the inside of one arm assembly with 2 1/2" pocket hole screws and wood glue.






Cut the front runner to size and drill 1 1/2" pocket holes at both ends. Attach it to the inside of the same arm assembly with 2 1/2" pocket hole screws and wood glue.





Attach the second arm assembly to the front and back runners with 2 1/2" pocket hole screws and wood glue.




8

Cut the seat slats to size, place them on top of the arm assembly cleats, according to the spacing below, and attach them to the cleats with 2 1/2" wood screws and wood glue.




9

Cut the back pieces to size. Drill 1 1/2" pocket holes at each end of the short pieces. Attach them to the long pieces with 2 1/2" pocket hole screws and wood glue.




10

To attach the back, rest it on the cleats, flush at the 5° angle of the cleats. Drive 2 1/2" screws from the bottom of the cleats into the back. Then, drive 2 1/2" screws from the back of the back runner into the back to secure.



Fill in your exposed screw holes, sand the entire piece down and give it a finish and follow up with an outdoor protectant.



Make sure to share your builds with us on social media and use #shanty2chic so we can share them too! Happy Building!