

Shanty Chic

DIY FURNITURE - WOODWORKING - HOMEMAKING



SUPPLY LIST


Item	Quantity	Description
2x6x8	4	Framing Lumber
2 1/2" Pocket Hole Screws		
Wood Glue		Link in Post on Our Site
Finish		Link in Post on Our Site
Outdoor Sealant		Optional

Remember!

Many of these cuts are best made as you go. If you have questions, check out the tutorial on our site!



CUT LIST

Note: I ripped the 2x6x8 boards down to 4 1/2" and 5" wide. This is not a necessary step but if you choose not to rip your boards, adjust the plans accordingly.




1

Cut the planked boards to size and drill 1 1/2" pocket holes at both ends of each board. Attach them to each leg assembly leaving about 3/8" gap between the planks. Attach with 2 1/2" pocket hole screws and wood glue.




2

Next, cut the leg pieces to size and drill 1 1/2" pocket holes on one end of each leg piece. Attach the legs to the breadboard pieces using 2 1/2" pocket hole screws and wood glue.



3

Cut the runners to size and drill 1 1/2" pocket holes at both ends. Attach them between the legs, 2 1/2" from the bottom of each leg.



Fill any visible pocket holes with wood filler and sand the entire table down.

Add an outdoor finish or make sure to seal it with an outdoor protectant!

Make it your own! Be sure to share your builds with us on social media so we can share them too!

Happy Building!

